

Bradfield Road, West Lindfield NSW 2070

Certificate of Approval NMI 6/9C/314

Issued by the Chief Metrologist under Regulation 60 of the
National Measurement Regulations 1999

This is to certify that an approval for use for trade has been granted in respect of the instruments herein described.

Bilanciai Model PTE-LW Weighing Instrument

submitted by National Weighing & Instruments Pty Ltd

1/88 Magowar Road

Girraween NSW 2145

NOTE: This Certificate relates to the suitability of the pattern of the instrument for use for trade only in respect of its metrological characteristics. This Certificate does not constitute or imply any guarantee of compliance by the manufacturer or any other person with any requirements regarding safety.

This approval has been granted with reference to document NMI R 76, Non-automatic weighing instruments, Parts 1 and 2, dated July 2004.

This approval becomes subject to review on 1/07/20, and then every 5 years thereafter.

DOCUMENT HISTORY

Rev	Reason/Details	Date
0	Pattern and variants 1 to 4 approved – certificate issued	25/06/15

CONDITIONS OF APPROVAL

General

Instruments purporting to comply with this approval shall be marked with pattern approval number 'NMI 6/9C/314' and only by persons authorised by the submittor.

It is the submittor's responsibility to ensure that all instruments marked with this approval number are constructed as described in the documentation lodged with the National Measurement Institute (NMI) and with the relevant Certificate of Approval and Technical Schedule. Failure to comply with this Condition may attract penalties under Section 19B of the National Measurement Act and may result in cancellation or withdrawal of the approval, in accordance with document NMI P 106.

Auxiliary devices used with this instrument shall comply with the requirements of General Supplementary Certificate No S1/0B.

Special

This approval shall NOT be used in conjunction with General Certificate No 6B/0.

Signed by a person authorised by the Chief Metrologist to exercise their powers under Regulation 60 of the *National Measurement Regulations 1999*.

Dr A Rawlinson

TECHNICAL SCHEDULE No 6/9C/314

1. Description of Pattern

approved on 25/06/15

The Bilanciai model PTE-LW is a class single interval self-indicating non-automatic weighing instrument of 1250 kg maximum capacity with a verification scale interval of 1 kg fitted to a forklift truck (Figure 1 and Table 1).

The instrument is intended to operate only whilst the forklift and its carriage are stationary (i.e. not whilst the forklift is in motion, or whilst the load is being moved). It is however acceptable for the forklift or load to be moved between the zeroing of the instrument and the weighing of the load.

Instruments may be fitted with output sockets (output interfacing capability) for the connection of auxiliary and/or peripheral devices.

1.1 Load Receptor

The load receptor consists of two Bilanciai WT-25 weighing modules fitted to a forklift truck, and on which are mounted two lifting forks as shown in Figure 1a.

Each Bilanciai WT-25 weighing module (Figure 1b) contains one tension type load cell within a linkage mechanism. The weighing modules are intended to be located on the forklift carriage, with the lifting forks (tines) being supported by the weighing modules.

1.2 Load Cells

A single Zhonghang Electronic Measuring Instruments Co., Ltd. (ZEMIC) model B3G-C3-5.0t load cell of 5000 kg maximum capacity is used in each weighing module.

1.3 Levelling

A Measurement Specialties model 25/E2 tilt sensor (inclinometer) is fitted within one of the Bilanciai WT-25 weighing modules, such that it will reflect tilting of the lifting forks, and will detect the degree to which the instrument is tilted from its reference (level) condition.

This tilt sensor provides a signal to the indicator. The indicator imposes limits on the level condition, automatically compensates for out of level conditions in longitudinal or transverse directions, and disables the weight determination if acceptable levels of tilt are exceeded (nominally 1.4° tilt from horizontal).

1.4 Indicator

A Bilanciai model D430 digital indicator (Figure 2) is used, and is connected to the Bilanciai WT-25 weighing module (which contains the tilt sensor). The indicator is also described in approval NMI S429.

1.4.1 Zero

The initial zero-setting device has a nominal range of not more than 20% of the maximum capacity of the instrument.

The instrument has a semi-automatic zero-setting device with a nominal range of not more than 4% of the maximum capacity of the instrument.

A zero-tracking device may be fitted (however see note below).

Note: There is a risk that the zero-tracking device of an instrument may inappropriately track zero where the instrument load receptor is not actually at zero – resulting in weighing errors. For this type of instrument this risk is heightened (e.g. due to long thin wedge like tines lowering a pallet, leaking of lift cylinder, etc). Hence in most usage situations it is recommended that the zero-tracking device be disabled.

1.4.2 Display Check

A display check is initiated whenever power is applied.

1.4.3 Additional Features

Instruments may be fitted with a number of additional functions including set-point facility and counting ('pcs'). These functions and displays are not approved for trade use.

1.4.4 Power Supply

The indicator may be powered by 12 V DC power source (e.g. from the forklift truck battery) or other DC power source. A Bilanciai model 460705 voltage conversion/regulation unit may be used – the submittor should be consulted regarding the acceptability of alternative power supply arrangements.

1.4.5 Interfaces

Instruments may be fitted with interfaces for the connection of auxiliary and/or peripheral devices. Any interfaces shall comply with clause 5.3.6 of document NMI R76 (the basic intent of which is that it shall not be possible to alter weighing results via the interfaces).

Any measurement data output from the instrument or its interfaces shall only be used for trade in compliance with General Supplementary Certificate No S1/0B (in particular in regard to the data and its format).

1.5 Descriptive Markings

Instruments are marked with the following data, together in one location, in the form shown at right:

Manufacturer's mark, or name written in full	Societa Cooperativa Bilanciai Campogalliano a.r.l., Italy	
Indication of accuracy class	(II)	
Pattern approval number for the instrument	NMI 6/9C/314	
Maximum capacity	<i>Max</i> kg #	
Minimum capacity	<i>Min</i> kg #	
Verification scale interval	e = kg #	
Serial number of the instrument		

These markings are also shown near the display of the result if they are not already located there.

1.6 Verification Provision

Provision is made for the application of a verification mark.

1.7 Sealing Provision

Provision is made for access to the calibration link within the instrument to be sealed as described in the approval documentation of the indicator.

2. Description of Variant 1

approved on 25/06/15

The Bilanciai model PTE-LW system as described for the pattern but of different models of differing capacities which use weighing modules as indicated in Table 1 below. (The model of weighing module described for the pattern is shown in **bold**.).

TABLE 1

Model	Maximum capacity (kg)	Verification Scale Interval (kg)	Carriage height (mm)	Load cell
WT-25	1250	1	406 (Fork II)	B3G-C3-5.0t
WT-25	2500	2	406 (Fork II)	B3G-C3-5.0t
WT-45	4500	5	508 (Fork III)	B3G-C3-5.0t

Note: Forklift carriage sizes are also allocated 'classes'. Care shall be taken to distinguish these classes from the non-automatic weighing instrument class (which is represented within an oval).

These models may be configured to have a maximum capacity less than shown above, and/or to have a verification scale interval greater than that shown in the table above, provided that:

- the number of verification scale intervals (i.e. Max / e) shall be not less than 500, and no more than 1250.
- the minimum capacity shall not be less than 20 e.

3. Description of Variant 2

approved on 25/06/15

The Bilanciai model PTE-LW system as described for the pattern but configured as a multiple range weighing instrument. Different models may be of differing capacities and use weighing modules with alternative load cells as indicated in Table 2 below.

TABLE 2
See Table 1 in Variant 1 for carriage height and load cell details

Model		Maximum capacity (kg)	Verification Scale Interval (kg)	Minimum capacity (kg)
WT-25	Low range	1250	1	20
	High range	2500	2	40
WT-45	Low range	2500	2	40
	High range	4500	5	100

Note: There is a risk that the instrument may reset zero inappropriately when returning to the low range from the high range. Hence in most usage situations it is recommended that the ability to automatically return to the low range be disabled.

These models may be configured to have a maximum capacity less than shown above, and/or to have a verification scale interval greater than that shown in the table above, provided that:

- for each range, the number of verification scale intervals (i.e. Max / e) shall be not less than 500, and no more than 1250.
- the minimum capacity shall not be less than 20 e.

4. Description of Variant 3

approved on 25/06/15

The Bilanciai model PTE-LW as a class non-automatic weighing instrument similar to the pattern and variant 1, however:

- the number of verification scale intervals (i.e. Max / e) shall be not less than 100, and no more than 1000.
- the minimum capacity shall not be less than 10 e.

5. Description of Variant 4

approved on 25/06/15

The Bilanciai model PTE-LW class ① or ② non-automatic weighing instrument similar to the pattern and variants, however using a Bilanciai model EV7S digital indicator rather than the model D430 indicator described for the pattern. The Bilanciai model EV7S indicator is also described in approval NMI S618.

TEST PROCEDURE No 6/9C/314

Instruments shall be tested in accordance with any relevant tests specified in the National Instrument Test Procedures (NITP), taking into account the following notes.

The instrument shall not be adjusted to anything other than as close as practical to zero error, even when these values are within the maximum permissible errors.

Maximum Permissible Errors

The maximum permissible errors are specified in Schedule 1 of the *National Trade Measurement Regulations 2009*.

Notes:

Levelling Arrangements and Stability of Ground

The site chosen for weighing should be firm and within 1.5 degrees of level – the level sensing device imposes limits on the level condition, however the stability of the ground surface should also be considered as well as safety concerns.

Gravity Variation

Where the instrument is verified in one location and subsequently moved to another location, the effects of differences in the acceleration of gravity at each location may need to be considered.

Note: The Trade Measurement Section should be consulted regarding any special arrangements which may be necessary in regard to operation of a mobile weighing instrument of this type.

Testing shall be carried out with the forks with which the instrument is to be used in normal operation, and also with the load applied in a manner similar to normal operation (e.g. for an instrument used for weighing pallets, fit the weighing instrument to a forklift truck, place an empty standard size ($1200 \times 1200 \text{ mm}$, nominal) hardwood/plastic pallet on the forks and raise above the ground.

Testing shall be carried out with the instrument having zero set using an initial zero-setting or semi-auto zero-setting device with a pallet on the forks and having the forks tilted to their reference (level) condition.

Tests (in addition to those in the NITP)

1) Eccentricity


Using a known load of approximately 1/3 *Max*, carry out tests to determine whether operation is within the maximum permissible errors with this load at the left, right, front and rear of the pallet.

2) Tilting

Carry out tests to determine whether operation is within the maximum permissible errors, with loads of ½ *Max* and close to *Max* by having the forks tilted to their reference (level) condition and then having the forks tilted forward until the instrument is disabled (weighing display showing 'Er.Slope') and gradually reducing the degree of tilt until a weight value is reacquired.

Repeat the test with the forks tilted backward.

FIGURE 6/9C/314 - 1



(a) Typical Mounting to a Forklift Truck




(b) Weighing Module
Bilanciai Model PTE-LW Weighing Instrument

FIGURE 6/9C/314 - 2



Bilanciai Model D430 Digital Indicator





Tilt sensor module

Tilt Module Shown Within Weighing Module